

# ENERGY PLUS

## ANALIZADOR DE RED MONOFÁSICO AC / DC (TRMS)

VAC  
IDC  
COSφ  
VRMS  
ARMS  
W  
Hz  
**PANTEC**


SOFTWARE DE CONFIGURACIÓN GRATUITO

REGISTRADOR POR PENDRIVE

Conexión microUSB

PROGRAMACIÓN POR CABLE

**i** ..10A  
**AC/DC** ENTRADAS  
**v** ..600VAC  
..1000VDC



**0-4/20mA** **RS485**

**SALIDAS**

**0/10V** **RELÉ**

**ALIMENTACIÓN 24VDC-AC**

### CARACTERÍSTICAS

- Analizador de red monofásico AC/DC (TRMS) aislado.
- Convertidor de señal 1000VDC / 600VAC, 10A AC/DC. \* versión -L (100VDC / 60VAC).
- Medición de energía, tensión, intensidad, potencia, frecuencia, ..
- Configurable a través de USB, mediante software gratuito.
- Montaje en raíl DIN. Bornas enchufables.
- Alimentación 24VAC/DC.
- Salidas: analógica, de contacto de alarma y Modbus RS485.
- Registrador a través de memoria externa USB y posibilidad de descarga de datos en formato Excel.
- Reloj RTC integrado, con tiempo real.

# CONEXIONADO y CARACTERÍSTICAS

**ALIMENTACIÓN**

DC	10.. 40Vdc
AC	20.. 28Vac

**24VAC/DC**

ALIMENTACIÓN

## ASLAMIENTO

ENTRADA	⚡
ALIMENTACIÓN	
RS485 Y USB	
SALIDA ANALÓGICA Y DIGITAL	

4 vías

<b>INTENSIDAD</b> Pasiva / Activa
0-4/20mA configurable
Resistencia de carga máxima <b>600Ohm</b>
<b>TENSIÓN</b>
0/10V configurable
Resistencia de carga mínima <b>2KOhm</b>
<b>Relé de alarma</b>
30V/50mA SPDT programable por software
<b>RS485 Modbus</b>
Configurable


**SALIDA**

configuración para programar (neutra)



## INDICACIÓN DE LEDS

- **POWER** Alimentación correcta
- **FAIL** Fallo en el equipo
- **Rx / Tx** Comunicación RS485 activa (led parpadeante)
- **DOUT** Salida digital activa



SALIDAS

ENTRADAS

## ENTRADA

<b>TENSIÓN</b>	versión -L
0.. 1000Vcc / ..600Vac	0.. 100Vcc / ..60Vac
<b>INTENSIDAD</b>	
0.. 10A (AC) / 0.. 10A (DC)	
mayores DE 10A (AC) TRAFO /5	

② ① UNIDOS INTERNAMENTE

## REGISTRADOR CON RELOJ



Pendrive micro USB  
Exportación a Excel  
(formato .csv)


\* Pendrive opcional

## AMBIENTALES

Temperatura de trabajo	- 15/+65°C
Temperatura de almacenamiento	- 40/+85°C

## FORMATO

Protección	<b>IP20</b>
Clase de combustibilidad Vo según UL94	
Caja Ergonómica. Montaje rápido rail EN50022	
Material Poliamida	<b>PA6.6</b>
Conexión: bornas enchufables por tornillo	
par de apriete tornillos(M3)	<b>0,5Nm</b>
Cable conexión: <2,5mm <sup>2</sup> , 12AWG 250V/12A	
Peso	<b>90 grs</b>




# INSTRUCTION MANUAL

## DESCRIPTION:

The ENERGY Plus is an isolated VOLTAGE and CURRENT converter and SINGLE PHASE NETWORK ANALYZER. The module has a programmable analog output (voltage or current) and a digital output (optomos). Thanks to the presence of the RS485 serial port can perform advanced functions such as I / O Module with Modbus RTU protocol. The ENERGY Plus behaves as a slave device by placing Current or Voltage Input, n°1 AO and n°1 DO.

## ELECTRICAL CONNECTIONS



### POWER SUPPLY:

10...40 Vdc or 20...28 Vac - Connectors 16 and 17, or by T-BUS connector (optional tool) on the base of the module (see the picture placed on the bottom of this page).


### VOLTAGE/CURRENT INPUT (DIRECT INSERTION):

the input Voltage (LINE) has to be connected on terminals 2 (+) and 8, the Load has to be connected on terminals 1 (+) and 6.

FOR VOLTAGE: up to 600 VAC, 1000 VDC (up to 60 VAC, 100 VDC for LV version).  
FOR CURRENT: up to 10 A AC/DC.

You can set the measurement range as per your need using the software or by RS485 using the modbus registers.

### INSERTION WITH EXTERNAL CURRENT TRANSFORMER (CT):







The input Voltage (LINE) has to be connected on terminals 2 (+) and 8 (as for the direct insertion).

The external CT (current transformer), must be connected as follows:

- S1 terminal of the CT connected to the terminal 6;
- S2 terminal of the CT connected to the terminal 8.

For the connection of the LOAD to the CT, follow the wiring diagram on the left side (INPUT P1 side and OUTPUT P2 side).

**WITH THIS CONFIGURATION, SET THE CURRENT RATIO VIA FACILE SOFTWARE (SEE PAGE 3).**



### ANALOG OUTPUT:

for Voltage analog output, connect terminals 31 and 29 (positive).

For ACTIVE current analog output, connect terminals 29 (positive) and 30. For PASSIVE current analog output, connect terminals 30 (positive) and 31. Analog output supply: 13 Vdc, max 30 mA.

### DIGITAL OUTPUT:

relay Output is an Optomos contact. Connection are with terminals 25 and 26. The contact can be used like an pulse output (you can set by FACILE the value of the pulse) or like Alarm contact (you can set the associated parameter by FACILE).

### SERIAL OUTPUT RS485:

available on connectors 32 (GND), 33 (B-), 34 (A+), or by T-BUS connector to be mounted on the module.

### T-BUS CONNECTION (OPTION), needs T-BUS connector:




it may be affixed to the accessory T-BUS based on the module to bring both power and serial communication. The number of modules supported by the bus is a function of the power supply used (check the absorption of the modules).

## SETTING THE DEVICE VIA SOFTWARE

The programming of the module may be performed in two different ways:

- via the free interface program through the microUSB port on the module or via RS485 connection;
- via the RS485 serial connection (from terminal or T-Bus).

The ENERGY Plus has two microprocessors, you can configure the module by connecting it to the USB port of your PC without the power lead, this is possible because the microprocessor that manages the configuration is powered directly from the USB port.




It is possible to use the program without connecting to the module, in this mode you can SAVE the configuration on your PC, which can then be sent to the ENERGY Plus at a later time.

### **SERIAL PORTS AVAILABLE:**



Check the available COM ports, press the UPDATE button. Your PC will assign a virtual COM connection with the ENERGY Plus. Press START CONNECTION WITH THE DEVICE. It will confirm you the connection was successful with the module. If the connection does not happen, please check the RS485 serial connection (A +, B-), the position of the dip-switches (switching off and on the device) and the COM generated automatically by the device. After connecting, you can proceed with the configuration of the device.

### **CURRENT RATIO, PULSE MANAGEMENT, FILTERS & CUT-OFF SETTINGS:**

This step on the software allow to define the Current Ratio by setting "CURRENT RATIO". The Pulse weight of the digital output can be setted by the WEIGHT IMPULSE FOR ENERGY CALC (Wh). RMS FILTER and AVERAGE FILTER COEFFICIENT are two different types of filters that allow you to introduce a delay of the answer in order to have more stability of the reading. CUT OFF settings: you can set the cut off values for VOLTAGE, CURRENT and POWER measurement. Under these value setted the measurement will be Zero.



## SETTING THE DEVICE VIA SOFTWARE



### **FAIL MESSAGE / ANOMALY:**

**FAIL HW:** problems in the measurement chain (electrical connections, microprocessor that manages the measurement, sensor disconnected or faulty).

**FAIL LOG:** problem on recording data (without the availability of stick usb memory stick usb not recognized).

**FAIL RTC:** problem on backup battery (dead or defective).

**FAIL EEPROM:** problem microprocessor configuration (not calibrated module, takes no configuration).

### **MODBUS COMUNICATION:**

This is the last window of the device configuration. The left column contains the parameters to be set for the communication speed BAUDRATE (from 1200 to 115200), the PARITY (None, Odd, Even), the STOP BIT (1 or 2), the Modbus address to be assigned to the device. You do not need to configure these parameters for the use of the module with digital / analog output. It is possible to use the module with RS485 serial output with Modbus output analog and digital simultaneously.

### **LOGGING :**

On the right side of the window you can enable the feature LOG for the acquisition of data on usb pendrive. You can name the log file by associating the extension .Xls, .Xlsx, .Csv, .Txt, .Dat, .Logs. The default file is in text format. The minimum sampling time is 1 second, the maximum is about 18 hours.

**ANALOG OUTPUT:** the first drop-down menu in the upper left allow you to associate the analog output to a single selectable **Vrms, Irms, Active Power, Reactive Power, Apparent Power, Cosφ, Frequency**.


The mode of the analog output is VOLTAGE or CURRENT. The ENERGY Plus as the ability to scale the input and output as required, then select the measurement range of input (INPUT BEGIN SCALE and INPUT END SCALE) to assign to the analog output signal (OUTPUT BEGIN SCALE and OUTPUT END SCALE). Depending on the choices made in the two menu will change the units of measurement values in the input and output. If you select the MANUAL CONTROL (via modbus), you can manage the module as if it were an AO (Analog Output), thus freeing the analog output from the input selected. The analog output will be handled via RS485 Modbus RTU (see register map).

**DIGITAL OUTPUT:** the digital output default set is NOT ACTIVE. If you want to ACTIVE the digital output please set it on the right window.

**ALLARM / FAIL ANALOG OUTPUT:** it is possible to use the analog output to control any supervening anomaly Hardware HW FAIL, FAIL RTC Real Time Clock anomaly that stores the date and time, FAIL EEPROM for the anomaly on the microprocessor, FAIL LOG if an anomaly occurred during data acquisition, UNDER RANGE scale of measurement set, OVER RANGE scale of measurement set. It is possible to select multiple items in the menu. In case of alarm the analog output will go to 21 mA or 10.5 V depending on the selection made in the previous window.

**ALARM WINDOW:** you can activate the ALARM functionality (in the gray box), on the digital output or on the analog output, or both simultaneously. In this window you can manage HOW and WHEN activate the alarm by selecting the options from the dropdown menu: MORE THAN A THRESHOLD, LESS THAN A THRESHOLD, NOT BETWEEN TWO THRESHOLD, BETWEEN TWO THRESHOLD. We therefore have the possibility to insert the values of THRESHOLD and the value of HYSTERESIS. In the case where it is selected the value of a **Higher threshold** when the signal falls below, the alarm switched off at the threshold value minus the value of hysteresis. In the event that you have chosen the value of a **Minor threshold**, when the value exceeds the threshold plus the hysteresis value, the alarm is deactivated. In the case where it is selected **between two thresholds**, the hysteresis is external. In case you have selected **Not included between two thresholds**, the hysteresis is internal.

**ALARM / FAIL DIGITAL OUTPUT:** it is possible to use the digital output to control any supervening anomaly Hardware HW FAIL, FAIL RTC Real Time Clock anomaly that stores the date and time, FAIL EEPROM for the anomaly on the microprocessor, FAIL LOG if an anomaly occurred during data acquisition, UNDER RANGE scale of measurement set, OVER RANGE scale of measurement set. It is possible to select multiple items in the menu. By clicking on the "ENABLE ENERGY PULSE" is enabled the pulse. STATE DIGITAL ALARM / FAIL allows you to define the status of contact in case of alarm (NOT ACTIVE or ACTIVE).



# DATALOGGER

Serial Number	Data (yyyy-mm-dd) & Time	Status ID	Vpk	lpk	Vrms	Irms	P	Q	S	Cosφ	Freq Total	Energy	Energy +	Energy -	Output Value	Output Type
12345678	2015/03/12-14-23-25	0	270	0	123		85,7			0,91	52	21	0			
12345678	2015/03/12-14-23-26	0	270	0	123		88,3			0,92	52,6	21	0			
12345678	2015/03/12-14-23-27	0	273	0	123		87,8			0,92	52,4	21	0			
12345678	2015/03/12-14-23-28	0	273	0	123		88,1			0,93	52,1	21	0			

The ENERGY Plus provides, on a local memory type PEN DRIVE USB (USB KEY) connected to the module via the microusb port, a series of information concerning the operation of the module, alarm status, type of input, the output type, the reading of the measured data, the measure of the output value from the module.


For each row correspond to a precise time reference. The module is equipped with an RTC Real Time Clock powered by a backup battery that lets you record data with YEAR / MONTH / DAY / HOUR-MIN-SEC.

The first number listed is the **SERIAL NUMBER** of the module, which allows it to be uniquely identified.

The second column give you information about: **DATE** (YEAR / MONTH / DAY / HOUR-MIN-SEC).

It is then reported the **STATUS ID** (Registry STATE) in binary mode to 16 bit. The binary number corresponds to the Modbus register 40005 that represents the state of the machine (Status: bit 0 = fail global, bit 1 = alarm, bit 2 = over range, bit 3 = under range, bit 4 = ?, bit 5 = dout status, bit 6 = fail hw, bit 7 = fail log, bit 8 = fail rtc, bit 9 = fail eeprom).

The following columns are **Vpk**, **lpk**, **Vrms**, **Irms**, **Active Power (P)**, **Reactive Power (Q)**, **Apparent Power (S)**, **Cosφ**, **Frequency**, **Energy Total**, **Energy +**, **Energy -**, **Output Value**, **Output type** ( bit 0=Voltage/Current, bit 1-4=input Vrms, Irms, Active Power, Reactive Power, Apparent Power, Cosφ, Frequency, bit 5 = fail ur, bit 6 = fail or, bit 7 = fail hw, bit 8 = fail log, bit 9 = fail rtc, bit 10 = fail eeprom, bit 11 = fail alarm, bit 12-13 = 1 threshold over/1 threshold min/2 thresholds external/2 threshold internal, bit 14 = Manual mode), this value follows the setting made via software or via RS485.





## LIVE DATA USING SOFTWARE

once confirmed the configuration, the software allow you to see the data reading by the device directly. Please remind that you have to supply the device by external power supply .


## HOW TO IMPORT LOG DATA FROM EXCEL VERSION BEFORE 2003:

it's possible to import the data stored on the USB Memory Stick at any time (even if the log is not finished). Once you open the file with Excel (or Open Office), you will have to act on the functionality of the program for wrapping the data as described above. To do this, you can perform the following steps: select the first column, go to the option data, click on TEXT COLUMN, then choose the option that provides for the separation of the data by tabs or commas, the next step endorse the option POINT and COMMA.



	A1	B	C	D	E	F	G	H	I
1	12345678	2014/03/1	0	27.36	0	0	10000	359	
2	12345678	2014/03/1	0	27.36	0	0	10000	359	
3	12345678	2014/03/1	0	27.36	0	0	10000	359	
4	12345678	2014/03/1	0	27.36	0	0	10000	359	
5	12345678	2014/03/1	0	27.36	0	0	10000	359	
6	12345678	2014/03/1	0	27.5	0	0	10000	361	
7	12345678	2014/03/1	0	27.5	0	0	10000	361	
8	12345678	2014/03/1	0	27.5	0	0	10000	361	
9	12345678	2014/03/1	0	27.5	0	0	10000	361	
10	12345678	2014/03/1	0	27.5	0	0	10000	361	
11	12345678	2014/03/1	0	27.5	0	0	10000	361	
12	12345678	2014/03/1	0	27.36	0	0	10000	359	
13	12345678	2014/03/1	n	27.36	n	n	10000	359	204

## QUICK GUIDE



### MODBUS ADDRESS CONFIGURATION AND BAUD RATE BY DIP-SWITCH

Through the dip-switch on the front panel of the module, you can change the Modbus address and baud rate. In the case in which all the dip switches are set to zero, the module will take the calibration from EEPROM, otherwise it will take parameters from a dip-switch. In order to assign addresses more than 62 assignments you need to take advantage of the interface software. In order to assign values of baud rates different from those selectable dip you should take advantage of the interface software.. For changing the addresses and the baud rate it can also be done by writing directly on the related registers.

### POWER SUPPLY

10...40 Vdc or 20...28 Vac - Connectors 16 and 17, or by T-BUS connector (optional tool) on the base of the module.

### POWER SUPPLY by T-BUS CONNECTION (T-BUS connector required):

it is possible to mount the accessory T-BUS to carry both power and serial communication. The number of modules supported by the function of the power supply bus is used (check the absorption of the modules).

### INTERFACE PROGRAM

It is the configuration software for ENERGY Plus module. The software is free and downloadable from the website. To communicate with the module you have to connect via USB port directly on your PC. You can configure the module via RS485 using the registers' map on the website.

### LEDS - FRONT SIGNALS:

**Power:** power presence on the device.  
**Fail:** presence of a failure/error on the device. It is activated in the case have been activated by FAIL messages on software. One or more events FAIL are active.  
**Rx, Tx:** the module is communicating via RS485 (LED blinking).  
**Dout:** digital output active.

### MOUNTING INSTRUCTIONS:

To mount the card on DIN rail, we recommend to place the top of the form on the edge of the bar omega, then pushing the bottom until it clicks. The module is equipped with a slider fastening that will be pushed forward in order to ensure the perfect fastening of the module on the bar.

**NOTE:** through the hole on the case of ENERGY Plus (shown in the figure), you can access an internal DIP SWITCH. Turning up the "DIP 1" you can activate the dynamic terminating of the Modbus.



# Modbus Registers Map

Register Name	Comment	Register Type	R/W	Default Value	Range	Modbus Address
<b>Machine ID</b>	Machine ID (1)	Unsigned short	R	3		<b>40001</b>
<b>FW version</b>	Firmware version (0)	Unsigned short	R			<b>40002</b>
<b>STATUS</b>	Status : bit 0 = fail global, bit 1 = alarm, bit 2 = overrange, bit 3 = underrange, bit 4= ?, bit 5=dout status, bit 6 = fail hw, bit 7=fail log, bit 8=fail rtc, bit 9=fail eeprom	Unsigned short	R/W		0...65535	<b>40005</b>
<b>Output Value</b>	mV or uA	Unsigned short	R/W		0...20000	<b>40006</b>
<b>Digital Output</b>	bit 0=disabled/enabled	Unsigned short	R/W	0		<b>40007</b>
<b>Dip switch status</b>	bit 0-7=dip switch status, pos 1=bit 7,..., pos 8=bit 0	Unsigned short	R/W			<b>40008</b>
<b>Vrms</b>	Voltage measurement rms (V)	Float (MSW)	R/W		0...10000	<b>40009</b> <b>40010</b>
<b>Irms</b>	Current measurement rms (mA)	Float (MSW)	R/W		0...14000	<b>40011</b> <b>40012</b>
<b>P</b>	Active Power Measurement (W)	Float (MSW)	R			<b>40013</b> <b>40014</b>
<b>Q</b>	Reactive Power Measurement (VAR)	Float (MSW)	R			<b>40015</b> <b>40016</b>
<b>S</b>	Apparent Power Measurement (VA)	Float (MSW)	R			<b>40017</b> <b>40018</b>
<b>Cosφ</b>	Cosφ Measurement	Float (MSW)	R		0...1	<b>40019</b> <b>40020</b>
<b>Frequency</b>	Frequency Measurement (Hz)	Float (MSW)	R			<b>40021</b> <b>40022</b>
<b>THD</b>	THD Measurement	Float (MSW)	R			<b>40023</b> <b>40024</b>
<b>Energy</b>	Totale Energy Measurement (Wh)	Float (MSW)	R/W			<b>40025</b> <b>40026</b>
<b>Energy positive</b>	Only positive Energy Measurement (Wh)	Float (MSW)	R/W			<b>40027</b> <b>40028</b>
<b>Energy negative</b>	Only negative Energy Measurement (Wh)	Float (MSW)	R/W			<b>40029</b> <b>40030</b>
<b>V peak</b>	Instantaneous Voltage Peak (V)	Float (MSW)	R/W			<b>40031</b> <b>40032</b>
<b>I peak</b>	Instantaneous Current Peak (mA)	Float (MSW)	R/W			<b>40033</b> <b>40034</b>
<b>V MAX</b>	Max RMS Voltage (V)	Float (MSW)	R/W			<b>40035</b> <b>40036</b>
<b>V min</b>	Min RMS Voltage (V)	Float (MSW)	R/W			<b>40037</b> <b>40038</b>
<b>I MAX</b>	Max RMS Current (mA)	Float (MSW)	R/W			<b>40039</b> <b>40040</b>
<b>I min</b>	Min RMS Current (mA)	Float (MSW)	R/W			<b>40041</b> <b>40042</b>
<b>P MAX</b>	Max RMS Active Power (W)	Float (MSW)	R/W			<b>40043</b> <b>40044</b>
<b>P min</b>	Min RMS Active Power (W)	Float (MSW)	R/W			<b>40045</b> <b>40046</b>
<b>Q MAX</b>	Max Reactive Power (VAR)	Float (MSW)	R/W			<b>40047</b> <b>40048</b>
<b>Q min</b>	Min Reactive Power (VAR)	Float (MSW )	R/W			<b>40049</b> <b>40050</b>
<b>S MAX</b>	Max Apparent Power (VA)	Float (MSW )	R/W			<b>40051</b> <b>40052</b>
<b>S min</b>	Min Apparent Power (VA)	Float (MSW )	R/W			<b>40053</b> <b>40054</b>
<b>Cosφ MAX</b>	Max Cosφ	Float (MSW )	R/W			<b>40055</b> <b>40056</b>





# Modbus Register Map

## Modbus Registers Map

Register Name	Comment	Register Type	R/W	Default Value	Range	Modbus Address
<b>Cosp min</b>	Min Cosp	Float (MSW )	R/W			40057
						40058
<b>Frequency MAX</b>	Max Frequency (Hz)	Float (MSW )	R/W			40059
						40060
<b>Frequency min</b>	Min Frequency (Hz)	Float (MSW )	R/W			40061
						40062
<b>THD MAX</b>	Max THD	Float (MSW )	R/W			40063
						40064
<b>THD min</b>	Min THD	Float (MSW )	R/W			40065
						40066
<b>Vavg</b>	V average (V)	Float (MSW )	R			40067
						40068
<b>Iavg</b>	I average (mA)	Float (MSW )	R			40069
						40070
<b>Totalizer</b>	Total Pulse Dout	UINT 32 (MSW)	R			40071
						40072
<b>data L</b>	Calibration data L	UINT 16	R			40073
<b>data M</b>	Calibration data M	UINT 16	R			40074
<b>data H</b>	Calibration data H	UINT 16	R			40075
<b>Output Analog mode</b>	bit 0=Voltage/Current, bit 1-4=input Vrms,Irms, Active Power, Reactive Power, Apparent Power, cos (Φ), Frequency, bit 5 = fail ur, bit 6 = fail or, bit 7 = fail hw, bit 8 = fail log, bit 9 = fail rtc, bit 10 = fail eeprom, bit 11 = fail alarm, bit 12-13 = 1 threshold over/1threshold under/2thresholds external/2 thresholds internal , bit 14= Manual mode	UINT 16	R/W	0		40101
<b>Current Ratio</b>	Current Ratio	Float (MSW )	R/W	1		40102
						40103
<b>Output Analog Input Begin Scale</b>	Output Analog Input Begin Scale	Float (MSW )	R/W	0		40104
						40105
<b>Output Analog Input End Scale</b>	Output Analog Input End Scale	Float (MSW )	R/W	300		40106
						40107
<b>Output Analog Begin Scale</b>	Output Analog Begin Scale	UINT 16	R/w	0		40108
<b>Output Analog End Scale</b>	Output Analog End Scale	UINT 16	R/W	10		40109
<b>Delta ENERGY</b>	Delta Energy (Wh) per pulse (50ms)	Float (MSW )	R/W	10		40110
						40111
<b>Digital Output</b>	bit 0=default value, bit 1 = fail ur, bit 2 = fail or, bit 3 = fail hw, bit 4 = fail log, bit 5 = fail rtc, bit 6 = fail eeprom, bit 7 = fail alarm, bit 8-9 = manual/pulse/fail, bit 10=low/high	UINT 16	R/W	0		40112
<b>ALARM LOW</b>	Alarm Low Trip value	Float (MSW )	R/W	0		40113
						40114
<b>ALARM HIGH</b>	Alarm High Trip value	Float (MSW )	R/W	0		40115
						40116
<b>ALARM HYSTERESIS</b>	Alarm Hysteresis value	Float (MSW )	R/W	0		40117
						40118
<b>Modbus Address + Parity + StopBits</b>	MSB modbus address, bit 0-1 = parity none/odd/even, bit 2=stop bits 1/2	UINT 16	R/W	260		40119
<b>Modbus Baudrate</b>	value 0=1200,1=2400,2=4800,3=9600,4=19200,5=38400,6=57600,7=115200	UINT 16	R/W	5		40120
<b>Log Mode</b>	bit 0=disabled/enabled	UINT 16	R/W	0		40121
<b>Log Sample time</b>	Log sample time (s)	UINT 16	R/W	0		40122
<b>Log name</b>	Log name (15caratteri MAX)	UINT 16	R/W			40123
<b>Log name</b>	Log name (15caratteri MAX)	UINT 16	R/W			40124
<b>Log name</b>	Log name (15caratteri MAX)	UINT 16	R/W			40125
<b>Log name</b>	Log name (15caratteri MAX)	UINT 16	R/W			40126
<b>Log name</b>	Log name (15caratteri MAX)	UINT 16	R/W			40127
<b>Log name</b>	Log name (15caratteri MAX)	UINT 16	R/W			40128
<b>Log name</b>	Log name (15caratteri MAX)	UINT 16	R/W			40129
<b>Log name</b>	Log name (15caratteri MAX)	UINT 16	R/W			40130
<b>RMS Filter</b>	Coeff. Filter RMS (0.99990 – 0.99999)	Float (MSW )	R/W	0,99990		40131
						40132
<b>Average measurement filter</b>	Average measurement filter (0.99990 – 0.99999)	Float (MSW )	R/W	0,9990		40133
						40134

# Modbus Registers Map

Register Name	Comment	Register Type	R/W	Default Value	Range	Modbus Address
<b>Cut off Voltage</b>	Cut off Voltage (V)	Float (MSW )	R/W	0		40135
						40136
<b>Cut off Current</b>	Cut off Current (mA)	Float (MSW )	R/W	0		40137
						40138
<b>Cut off P</b>	Cut off P (W)	Float (MSW )	R/W	0		40139
						40140
<b>Vrms SW</b>	Vrms (V)	Float (LSW )	R			40201
						40202
<b>Irms SW</b>	Irms (mA)	Float (LSW )	R			40203
						40204
<b>P SW</b>	Active Power (W)	Float (LSW )	R			40205
						40206
<b>Q SW</b>	Reactive Power (VAR)	Float (LSW )	R			40207
						40208
<b>S SW</b>	Apparent Power (VA)	Float (LSW )	R			40209
						40210
<b>Cosφ SW</b>	Cosφ	Float (LSW )	R			40211
						40212
<b>Frequency SW</b>	Frequency (Hz)	Float (LSW )	R			40213
						40214
<b>THD SW</b>	THD	Float (LSW )	R			40215
						40216
<b>TOTAL ENERGY SW</b>	Total Energy (Wh)	Float (LSW )	R/W			40217
						40218
<b>Positive Energy SW</b>	Positive Energy (Wh)	Float (LSW )	R/W			40219
						40220
<b>Negative Energy SW</b>	Negative Energy (Wh)	Float (LSW )	R/W			40221
						40222
<b>Vpeak SW</b>	Vpk (V)	Float (LSW )	R/W			40223
						40224
<b>Ipeak SW</b>	Ipk (mA)	Float (LSW )	R/W			40225
						40226
<b>Vrms MAX SW</b>	Vrms MAX (V)	Float (LSW )	R/W			40227
						40228
<b>Vrms min SW</b>	Vrms MIN (V)	Float (LSW )	R/W			40229
						40230
<b>Irms MAX SW</b>	Irms MAX (A)	Float (LSW )	R/W			40231
						40232
<b>Irms min SW</b>	Irms MIN (mA)	Float (LSW )	R/W			40233
						40234
<b>P MAX SW</b>	Active Power MAX (W)	Float (LSW )	R/W			40235
						40236
<b>P min SW</b>	Active Power MIN (W)	Float (LSW )	R/W			40237
						40238
<b>Q MAX SW</b>	Reactive Power MAX (VAR)	Float (LSW )	R/W			40239
						40240
<b>Q min SW</b>	Reactive Power MIN (VAR)	Float (LSW )	R/W			40241
						40242
<b>S MAX SW</b>	Apparent Power MAX (VA)	Float (LSW )	R/W			40243
						40244
<b>S min SW</b>	Apparent Power MIN (VA)	Float (LSW )	R/W			40245
						40246
<b>Cosφ MAX SW</b>	Cosφ MAX	Float (LSW )	R/W			40247
						40248
<b>Cosφ min SW</b>	Cosφ min	Float (LSW )	R/W			40249
						40250
<b>Frequency MAX SW</b>	Frequency MAX (Hz)	Float (LSW )	R/W			40251
						40252
<b>Frequency MIN SW</b>	Frequency MIN (Hz)	Float (LSW )	R/W			40253
						40254

# Modbus Registers Map

## Modbus Register Map

Register Name	Comment	Register Type	R/W	Default Value	Range	Modbus Address
<b>THD MAX SW</b>	THD MAX	Float (LSW)	R/W			40255
						40256
<b>THD min SW</b>	THD MIN	Float (LSW)	R/W			40257
						40258
<b>Vrms x 100</b>	Vrms (V) x 100	SIGNED LONG(MSW)	R			40301
						40302
<b>Irms x 100</b>	Irms (mA) x 100	SIGNED LONG(MSW)	R			40303
						40304
<b>P x 100</b>	Active Power (W) x 100	SIGNED LONG(MSW)	R			40305
						40306
<b>Q x 100</b>	Reactive Power (VAR) x 100	SIGNED LONG(MSW)	R			40307
						40308
<b>S x 100</b>	Apparent Power (VA) x 100	SIGNED LONG(MSW)	R			40309
						40310
<b>Cosφ x 100</b>	Cosφ x 100	SIGNED LONG(MSW)	R			40311
						40312
<b>Frequency x 100</b>	Frequency (Hz) x 100	SIGNED LONG(MSW)	R			40313
						40314
<b>THD x 100</b>	THD x 100	SIGNED LONG(MSW)	R			40315
						40316
<b>ENERGY x 100</b>	Energy (Wh) x 100	SIGNED LONG(MSW)	R/W			40317
						40318
<b>Positive Energy x 100</b>	Positive Energy (Wh) x 100	SIGNED LONG(MSW)	R/W			40319
						40320
<b>Negative Energy x 100</b>	Negative Energy (Wh) x 100	SIGNED LONG(MSW)	R/W			40321
						40322
<b>V peak x 100</b>	Vpk (V) x 100	SIGNED LONG(MSW)	R/W			40323
						40324
<b>I peak x 100</b>	Ipk (mA) x 100	SIGNED LONG(MSW)	R/W			40325
						40326
<b>Vrms MAX x 100</b>	Vrms MAX (V) x 100	SIGNED LONG(MSW)	R/W			40327
						40328
<b>Vrms min x 100</b>	Vrms MIN (V) x 100	SIGNED LONG(MSW)	R/W			40329
						40330
<b>Irms MAX x 100</b>	Irms MAX (mA) x 100	SIGNED LONG(MSW)	R/W			40331
						40332
<b>Irms min x 100</b>	Irms MIN (mA) x 100	SIGNED LONG(MSW)	R/W			40333
						40334
<b>P MAX x 100</b>	Active Power MAX (W) x 100	SIGNED LONG(MSW)	R/W			40335
						40336
<b>P min x 100</b>	Active Power MIN (W) x 100	SIGNED LONG(MSW)	R/W			40337
						40338
<b>Q MAX x 100</b>	Reactive Power MAX (VAR) x 100	SIGNED LONG(MSW)	R/W			40339
						40340
<b>Q min x 100</b>	Reactive Power MIN (VAR) x 100	SIGNED LONG(MSW)	R/W			40341
						40342
<b>S MAX x 100</b>	Apparent Power MAX (VA) x 100	SIGNED LONG(MSW)	R/W			40343
						40344
<b>S min x 100</b>	Apparent Power MIN (VA) x 100	SIGNED LONG(MSW)	R/W			40345
						40346
<b>Cosφ MAX x 100</b>	Cosφ MAX x 100	SIGNED LONG(MSW)	R/W			40347
						40348
<b>Cosφ min x 100</b>	Cosφ MIN x 100	SIGNED LONG(MSW)	R/W			40349
						40350
<b>Frequency MAX x 100</b>	Frequency MAX (Hz) x 100	SIGNED LONG(MSW)	R/W			40351
						40352
<b>Frequency min x 100</b>	Frequency MIN (Hz) x 100	SIGNED LONG(MSW)	R/W			40353
						40354

# Modbus Registers Map

Q

Register Name	Comment	Register Type	R/W	Default Value	Range	Modbus Address
<b>THD MAX x 100</b>	THD MAX x 100	SIGNED LONG(MSW)	R/W			<b>40355</b>
						<b>40356</b>
<b>THD min x 100</b>	THD MIN x 100	SIGNED LONG(MSW)	R/W			<b>40357</b>
						<b>40358</b>
<b>RTC YEAR</b>	RTC : year (2000-2099)	UINT16	R/W			<b>41001</b>
<b>RTC MONTH</b>	RTC : month (1-12)	UINT16	R/W			<b>41002</b>
<b>RTC DAY</b>	RTC : day month (1-31)	UINT16	R/W			<b>41003</b>
<b>RTC HOUR</b>	RTC : hour (0-23)	UINT16	R/W			<b>41004</b>
<b>RTC MINUTE</b>	RTC : minute (0-59)	UINT16	R/W			<b>41005</b>
<b>RTC SEC</b>	RTC : second (0-59)	UINT16	R/W			<b>41006</b>

## REMARKS:

- Modbus connections: A+ and B- as per Modbus RTU standards;
- Modbus Register reference: with reference to the logical address, for ex. 40010, corresponds to physical address n°9 as per Modbus RTU standard;
- Dip Switch Settings: the setting is not enabled if the first sixth dip-switches are set to 000000, the rest of dip-switch are disabled. All settings coming from EEPROM.
- Modbus functions supported: 3 (Read multiple registers), 6 (Write single), 16 (Write multiple).
- **Any changes made by dip-switch required to switch off the power supply**

